



How To Set Encoder Properties For Windows Printers In CardFive

First go to file and select card setup.


From the Magnetic encoder tab set the Start and End of data settings for track one as below:



From the drop down menu select track two and set as below:



From the drop down menu select track three and set as below:



Close CardFive and restart for the settings to take effect, and power cycle the printer.